

How to create straight section catalog numbers

1. Select the material
2. Select nominal width of tray
3. Select the bottom type
4. The last number is the length of the channel tray



Ventilated channel



Solid channel

Example:

ALTC04V-3

- Aluminum
- 4" wide
- Ventilated bottom
- 10 ft. length

Straight section number selection

