

# ERICO® FLEXIBAR® Accessories

## ERICO FLEXIBAR End Cover 20, 24 & 32

End Cover 20, 24 & 32

- End Cover 20: Accessory for ERICO FLEXIBAR 20 mm, IBS 25, IBS 50, IBSB 50 and IBSB 70.
- End Cover 24: Accessory for ERICO FLEXIBAR 24 mm and IBSB 100
- End Cover 32: Accessory for ERICO FLEXIBAR 32 mm, IBSBR 120, 185 and 240.
- Visual inspection of connection (transparent cover)
- Halogen-free
- Self-extinguishing: UL®94 V-0
- RoHS compliant
- Easy-fitting after bolting





Part No.	Description	12	kg/lbs
541774	End Cover 20	12	0.19/0.42
541775	End Cover 24	12	0.22/0.48
541776	End Cover 32	12	0.26/0.57

## FS ERICO FLEXIBAR Spacer Clamp



- Helps ensure correct support for ERICO FLEXIBAR, IBSB & IBSBR in parallel, without damage to the insulation.
- Helps ensure correct space for optimum cooling.
- 4 ERICO FLEXIBAR in parallel maximum
- UL 67
- Recommended distance between clamps: 16 inches.



Part No.	Description	Type*	H in	L in	25	lbs
553550	FS 24	=< 24 mm	2.08	1.18	25	0.03
553560	FS 32	=< 32 mm	2.08	1.49	25	0.04
553570	FS 40-63	40-50 & 63 mm	3.74	5.90	10	2.20
553580	FS 80-100	80/100 mm	5.51	7.87	10	5.51

\* Type of ERICO FLEXIBAR and IBS/IBSB/IBSBR

## ERICO FLEXIBAR Spacer Clamps

- Easy to install
- Provides support
- Allows for proper cooling

