

US27 fuse holder (without microswitch)

800Vac & dc

Number of poles	Connections	Cat. Number	Ref. Number	Weight (g)	Pack
1	By screw, U bolt or connector	US271I	J226420C	285	3
1 + N	By screw, U bolt or connector	US271NI	K226421A	580	1
1 + N	Ring lug connection	US271NIRING	E223518A	690	1
N	Ring lug connection	US27NIRING	F223519C	340	3
2	Ring lug connection	US272IRING	C223516A	690	1
3	By screw, U bolt or connector	US273I	M226423A	855	1
3	Ring lug connection	US273IRING	D223517A	1030	1
3 + N	By screw, U bolt or connector	US273NI	N226424A	1200	1
Assembly kit		US27PAK	H227615J		10
Microswitch*		US27W1	E227612A		1



* for the US27 version only

US27 fuse disconnecter (with microswitch)

800Vac & dc

Number of poles	Connections	Cat. Number	Nb of microswitches	Ref. Number	Weight (g)	Pack
1	By screw, U bolt or connector	US271MI	1	R227600C	320	3
1	Ring lug connection	US271MIRING	1	Z227607A	355	1
2	By screw, U bolt or connector	US272MI	1	S227601A	680	1
2	By screw, U bolt or connector	US272M2I	2	T227602A	600	1
2	Ring lug connection	US272M2IRING	2	B227609A	710	1

