
Internal Accessories for DG 150A and FG 250A Frames


Auxiliary Switch and Alarm Switch Combination Kits

Description	Mounting Pocket ^①	Catalog Number
1 Alarm Switch		
1A/B ^③	Left, Right ^②	ASKL1
Bases AMBL2 & AMBL3		
2 Aux. Switches		
1A + 1B	Left, Right	ASKL2
Bases AMBL1		
2 Aux. + 1 Alarm Switch		
1A + 1B, 1A/B ³	Left, Right ^②	ASKL3
Bases AMBL2 & AMBL3		



Auxiliary/Alarm Switch Mounting Base Only

Description	Mounting Pocket	Catalog Number
Up to 3 Auxiliary Switches	Left, Right	AMBL1
2 Aux. + 1 Alarm Switch	Left Pocket Only	AMBL2
2 Aux. + 1 Alarm Switch	Right Pocket Only	AMBL3




Auxiliary/Alarm Switch Only Common to DG - PG Frames


Description	Catalog Number
1 Normally Open Contact (1A)	ASWPA
1 Normally Closed Contact (1B)	ASWPB

Shunt Trips

Description	Mounting Pocket	Catalog Number
24 VDC		STRLB24DC
48-60 VDC		STRLC60DC
110-127 VDC		STRLD125DC
220-250 VDC	Right Pocket Only	STRLE250DC
48-60 VAC		STRLM60
110-127 VAC		STRLN120
208-277 VAC		STRLS277
380-600 VAC		STRLV600



Undervoltage Release





External Accessories pages 7-137 through 7-151

[®] Refer to the "Accessory Locations" chart on page 7-152 for guidelines and limitations about which pockets may be used for accessory combinations.

These kits include two bases, one for mounting switches in the left pocket and another for mounting in the right.Includes 1A and 1B contact for alarm purposes, only one of which may be installed at any time.

^{&#}x27;A' refers to a normally open contact (open when the breaker contacts are open).

^{&#}x27;B' refers to a normally closed contact (closed when the breaker contacts are open).